





# Submersible Borehole Pump

## Original Instruction Manual



5DWm



5DW

**LEO GROUP PUMP CO.,LTD**  
**LEO GROUP PUMP (ZHEJIANG) CO.,LTD**

📍 No.1,3rd Street, East Industry Center, Wenling, Zhejiang, 317511,P.R.China,

🌐 [www.leopump.com](http://www.leopump.com)    ✉ [export@leopump.com](mailto:export@leopump.com)

☎ +86-576-89986360    📠 +86-576-89989898



[www.leopump.com](http://www.leopump.com)

LEO reserves all the right of products modification without prior notification

Always disconnect the appliance from the supply before assembling, disassembling or cleaning.

Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

Children shall not play with the appliance.

Pumps without indication that they are protected against the effect of freezing shall not be left outside during freezing weather conditions

#### Attention!

If the appliance or the supply cord is damaged, it must be repaired by manufacturer, its service agent or qualified person.



#### Meaning of crossed –out wheeled dustbin:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact you local government for information regarding the collection systems available.

**ATTENTION: if the pump is temporarily used with dirty liquids or water containing chlorine, flush the pump briefly with clean water immediately after use to remove any deposit.**

If the pump has not been used for a long time and does not start or gives no water (but electrical connections are in order), the pump must be removed from the water and checked to see if it is choked by any foreign matter or blocked by sediment, deposits or any other cause.



**Disconnect electrical power before any servicing operation and make sure the pump cannot be accidentally switched on.**

## 6. Dismantling

### 6.1. Checking rotation of the shaft

Refer to the cross-section drawing on page 29. While the pump is positioned horizontally, remove the screws (14.24), the square nuts (14.28) and suction strainer (15.50). Hold the first stage casing (25.01) tightly with one hand so that it does not rotate and, with a wrench on the nut (28.04), turn the shaft in the anti-clockwise direction.

If the shaft is blocked and cannot be freed, dismantling should continue until the cause has been found and removed.

### 6.2. Inspection of the hydraulic parts

The O-ring (14.20) and then the complete motor assembly with all internal pump parts are removed from the external jacket (14.02). The first impeller can be inspected by removing the first stage casing (25.01). Once the nuts (28.04) and washer (28.08) are removed, the spacer sleeves (64.15), impellers (28.00) and the other stage casings (25.02 and 25.05) can be dismantled one after the other.

Other parts should not be dismantled.

**The motor and pump functions can be impaired by erroneous procedure or tampering with internal parts.**

### 6.3. Oil chamber

If the oil chamber has to be inspected, follow these instructions:



**CAUTION: there may be slight pressure in the oil chamber.**

Care must be taken to avoid a sudden spurting of oil. Wait until the oil chamber cover (34.03) has cooled down.

Before removing the mechanical seal (36.00) loosen the screws (70.18) and raise the cover (34.03), applying force simultaneously on two

opposite points of the cover rim, to let off pressure from the oil chamber. Carry out this operation while holding the motor in the upright vertical position.

When refilling the chamber use only white oil suitable for food machinery and pharmaceutical use (quantity = 35 g).

First, mount the fixed parts of the seal (36.00) on the oil chamber cover (34.00) and then the oil chamber cover (34.03) on the motor cover (70.00) with the O-ring (70.09).

## 7. Spare parts

When ordering spare parts, please quote their designation, position number in the cross section drawing and rated data from the pump name plate (type, date and serial number).

Any pumps that require inspection/repair must be sent back complete with cable and electric control box.

## 8. Designation of parts

### Nr. Designation


- 14.02 External jacket
- 14.20 O-ring
- 14.24 Screw
- 14.28 Square nut
- 14.54 Wear ring (1)
- 15.50 Suction strainer
- 25.01 First stage casing
- 25.02 Stage casing
- 25.05 Last stage casing
- 25.10 Washer for missing impeller
- 28.00 impeller
- 28.04 impeller nut
- 28.08 Washer
- 34.03 Oil chamber cover
- 36.00 Mechanical seal
- 36.51 Retaining ring, split
- 36.52 Shoulder ring
- 36.54 Spacer
- 64.15 Spacer sleeve
- 70.00 Motor cover, pump side
- 70.05 O-ring
- 70.09 O-ring
- 70.10 O-ring
- 70.12 Cable gland rubber ring
- 70.13 Washer
- 70.16 Cable gland
- 70.18 Screw
- 72.00 Upper mechanical seal
- 72.02 Circlip
- 73.00 Pump side bearing
- 76.01 Motor jacket with winding
- 76.60 Float switch
- 78.00 Shaft with rotor packet
- 78.12 O-ring
- 81.00 Bearing
- 82.01 Motor end-shield, non-drive end
- 82.02 Screw
- 82.03 O-ring
- 82.04 Compensating spring
- 82.05 Screw
- 92.00 Tie-bolt
- 96.00 Cable

(1) Inserted in the stage casing, cannot be supplied separately

(2) Oil

Changes reserved

## Cross section drawings



## Close coupled multi-stage submersible clean water pumps

### OPERATING INSTRUCTIONS

#### 1. Operating conditions

Standard construction

- For clean water with a maximum temperature of 35°C and maximum sand content of 60 g/m<sup>3</sup>
- Minimum internal diameter of well: 132 mm.
- Minimum immersion depth: 100 mm.
- Maximum submersion depth: 20 m (with suitable cable length).
- Maximum starts/hour: 30 at regular intervals
- Sound pressure at minimum immersion depth < 70 dB(A).
- Noise disappears when the pump is submersed.



**Do not use in ponds, tanks or swimming pools when people may enter or come into contact with the water.**


#### 2. Installation

The internal diameter of the delivery pipe must never be smaller than the diameter of the pump connection port: G 1 1/4" (DN 32).

The pump must be installed in the vertical position with the delivery connection facing upwards.

The pump can be installed immersed (min 100 mm) or submersed (max 20 m) either resting on a bottom surface or suspended.

#### 2.1. Pump in the resting position




Construction without float switch

Construction with float switch

The pump can be rested on the flat bottom surface of a tank.

**When sand or slime deposits are expected to form, mount the pump on a surface raised from the bottom level so that abrasive matter is not lifted.**

#### 2.2. Pump in the suspended position



1. Electric power cable
2. Delivery pipe
3. Safety rope
4. Pressure gauge
5. Air vent valve
6. Check valve
7. Gate valve

The pump can be held in a suspended position by the metal delivery pipe. Tighten the threaded pipe joints firmly to avoid loosening during operation.

Position the pump at a distance of at least 0.5 m from the bottom of a well so that sand is not lifted.

**A safety rope or chain** of non-perishable material should always be used to secure a suspended pump. When a plastic or flexible delivery pipe is used the safety rope or chain should be utilized for lowering, securing and raising the pump.



**Never use the electric power cable to suspend the pump.**

Attach the power supply cable to the delivery pipe and to the safety rope with cable clamps at intervals of about 3 m. The power cable should not be taut: allow for a certain degree of slackness between the clamps to avoid the risk of strain caused by expansion of the pipe during operation

#### 3. Electrical connection



Electrical connection must be carried out only by a qualified electrician in accordance with local regulations. Follow all safety standards.

Follow all safety standards.

**The unit must be always earthed, also with a non-metallic delivery pipe.**

**ATTENTION:** in the case of water containing chloride (or salt water), the earthing (grounding) conductor is useful also to reduce the risk of galvanic corrosion due to electrolytic action especially with non-metallic delivery pipe and safety rope.

Make sure the frequency and mains voltage correspond with the name plate data.

For use in swimming pools (not when people are in the pool), garden ponds and similar places, a residual current device with I<sub>Δ</sub>N not exceeding 30 mA must be installed in the supply circuit.

Install a device for disconnection from the mains (switch) with a contact separation of at least 3 mm on all poles.


When the water level is not under direct visible control, install a float switch or electrodes to protect the pump against dry running and to set the water levels to stop and automatically start the pump.

When extension cables are used, make sure the cable wires are of adequate size to avoid voltage drops. For connection of cables in a well, use thermo-shrinking sheathes or other methods for submersed cables.

#### 3.1. Single-phase pumps

Supplied with incorporated thermal protector. The motor will stop if overheating is detected. When the windings cool down (after 2 to 4 minutes), the thermal protector enables re-starting.

**Control box with starting capacitor is included in the scope of supply.**



Electrical diagram

#### 3.2. Three-phase pumps

Install in the control box an overload-protective device in accordance with the name-plate current.

#### 4. Starting

**With a three-phase power supply make sure the direction of rotation is correct.**

For this purpose, with the gate valve at any aperture position, check the pressure (with the pressure gauge), or flow rate (sight check) after starting. Switch off power, invert the connections of two phases on the control panel, re-start and check the pressure or flow rate capacity again.

The correct direction of rotation will provide a considerably greater and easily distinguishable pressure and delivery capacity.

Make sure the pump is operating within its range of rated performance and that the absorbed current indicated on the name-plate is not exceeded. Otherwise, adjust the delivery gate valve or the setting of pressure switches if installed.

**ATTENTION:** never allow the pump to run for more than five minutes with a closed gate valve.

**ATTENTION:** never run the pump dry, not even for a short trial run. Never start the pump before it has been immersed to a depth of at least 100 mm.

#### Construction with float switch:

the float switch, connected directly to the pump, controls starting and stopping. Check that the float switch is free from any obstacle.

If necessary, adjust the float-switch cable.

Excessive cable length may cause the motor to overheat and the pump to run dry.

#### Construction without float switch:

If there is no air vent valve in systems with a check valve, the minimum immersion depth at first start-up must be 300 mm. An air vent valve must be used in systems with an immersed delivery outlet.

Do not start the pump with a completely closed shut-off gate valve.

Never take the pump out of the water while the pump is still operating,

#### 5. Maintenance

Under normal operating conditions the pump will not require maintenance.

If freezing may be expected while the pump remains inactive and it is not submersed at a safe depth, remove the pump from the water and leave it in a dry place.